

Overview of programmes

Program/type of laundry/information	Settings
Name of the program: Brief explanation of the program and for which textiles it is suitable.	max. load** as Kg depending on the model and programme max temperature (— — = cold) Spin speed can be selected depending on the model and Programme max* additional settings that can be selected depending on the model
Cottons  : hard-wearing textiles, heat-resistant textiles made of cotton or linen Note: The  Speed setting is suitable as a short program for lightly soiled laundry.	6 kg/4** kg; — — to 90 °C ---, 400 - 1000* rpm  , 
Cottons 60°Label  : hard-wearing textiles, heat-resistant textiles made of cotton or linen Note: The actual washing temperature may differ from the stated programme temperature for energy-saving reasons; the washing performance corresponds to the selected temperature.	6 kg; ---, 400 - 1000* rpm 
Synthetics  : textiles made of synthetic materials or blended fabrics	3 kg; — — to 60 °C ---, 0 - 1000* rpm  , 
Mix Load  : mixed load of cottons and synthetic fabrics	4 kg; — — to 40 °C ---, 0 - 1000* rpm  , 
Delicates/Silk  : for delicate, washable textiles, e.g. made of silk, satin, synthetic fibres or blended fabrics (e.g. silk blouses, silk scarf) Note: Use a detergent suitable for machine-washing delicates or silk.	2 kg; — — to 40 °C ---, 0 - 800 rpm  , 
* maximum spin speed depends on the program and model ** reduced load for the  Speed setting and model	

Program/type of laundry/information	Settings
 Wool  : hand or machine-washable wool or rich-wool textiles. Especially gentle wash program to prevent shrinkage, longer program pauses (textiles rest in wash liquor).	2 kg; — to 40 °C ---, 0 - 800 rpm -
Notes - Wool is of animal origin, e.g.: Angora, alpaca, llama, sheep. - Use a detergent that is suitable for machine-washing wool.	
Drum Descaler  : Programme for cleaning and caring for the drum and the inner tub, Descaling helps to remove lime scale build up due to hard water	-; - 1000* rpm -
Notes - Run programme without laundry. - Use only Bosch descaler for front-loading washing machines. Do not use any other additional cleaning agents or mix the descaler with detergent.	
 Quick 15/30 min : extra short program of approx. 30 minutes, suitable for small items of lightly soiled laundry	2 kg/3.5** kg; — to 40 °C 0 - 1000* rpm ≡ 
Note: When selecting the ≡  Speed setting, the program Quick 15 is run.	
 Freshen Up : fabrics made from cotton or synthetics Short programme suitable for removing dust and sand from washing, e.g. after rainfall; washing warmer after the last rinse cycle, this may reduce the subsequent drying process.	2 kg; 30 - 60 °C 800 - 1000* rpm -
 Kidswear : hard-wearing fabrics, heat-resistant fabrics made of cotton or linen. Suitable for children's clothing	6 kg; — to 90 °C ---, 400 - 1000* rpm 
 AllergyPlus/Anti Bacteria : hard-wearing fabrics made of cotton or linen	4.5 kg; — to 60 °C ---, 400 - 1000* rpm ≡  
Note: Particularly suited to washing items that need to be hygienically clean and especially kind to sensitive skin thanks to the longer wash cycle at a defined temperature, higher water level and longer spin cycle.	
 Jeans/Dark Wash : Dark-coloured and colour-intense items made from cotton or easy-care fabric, e.g. jeans	2 kg; — to 40 °C ---, 0 - 1000* rpm ≡  
 Sportswear : Sportswear and leisurewear made from synthetic or microfibre fabrics or fleece.	2 kg; — to 40 °C ---, 0 - 800** rpm ≡  
* maximum spin speed depends on the program and model ** reduced load for the ≡  Speed setting and model	

Program/type of laundry/information		Settings
 Spin/Drain : Extra spin with selectable spin speed. Only to be emptied, set spin speed to 0. Note: The display of the Ready-in time is only updated once the program is restarted.		-;-
		0 - 1000* rpm
		-
 Rinse : extra rinse with selectable spin speed		-;-
		---,0 - 1000* rpm
		
* maximum spin speed depends on the program and model		
** reduced load for the  Speed setting and model		



Consumption values table

Programme	Load	Energy consumption*	Water*	Programme duration*
Cottons 20 °C	6 kg	0,25 kWh	76 l	2 3/4 h
Cottons 40 °C	6 kg	0,98 kWh	76 l	3 h
Cottons 60 °C Label	6 kg	0,40 kWh	45 l	5 1/2 h
Cottons 90 °C	6 kg	2,10 kWh	88 l	2 3/4 h
Synthetics 40 °C	3 kg	0,72 kWh	62 l	2 h
Mix Load 40 °C	4 kg	0,59 kWh	45 l	1 1/4 h
Delicates/Silk 30 °C	2 kg	0,21 kWh	36 l	3/4 h
Wool 30 °C	2 kg	0,25 kWh	35 l	3/4 h

* Observed values may deviate from the indicated values due to influence of water pressure, hardness and inlet temperature, ambient temperature, type, amount and soiling of laundry, detergent used, fluctuations in power supply and selected additional functions.

WLJ2016TIN WLJ2016WIN WLJ20161IN

9001513812 (0010)

