1 Consumption values

Additional consumption values in accordance with EN 60456, valid until 1st March 2021

The indicated consumption values are approximate. The values may deviate from the indicated values depending on water pressure, water hardness, water inlet temperature, room temperature, type of laundry, amount and soiling of laundry, detergent used, fluctuations in the mains voltage and selected settings.

Programme	Temper- ature (°C)	Load (kg)	Energy con- sump- tion (kWh) ¹	Water con- sump- tion (I) ¹	Pro- gramme duration (min) ¹	Residual moisture (%) ^{1, 2}
Cottons	20	9,0	0,370	90	208	52
Cottons 3	40	9,0	1,350	90	208	52
Cottons	60	9,0	1,450	90	208	52
Cottons colour	60	9,0	0,900	57	285	53
Cottons colour	60	4,5	0,590	46	285	53
Cottons colour	40	4,5	0,440	46	285	53
Easy Care 3	40	4,0	0,780	61	148	27
Mixed Load	40	4,0	0,620	44	59	53
Delicates/Silk	30	2,0	0,200	35	35	60
	30	2,0	0,200	40	40	25

values determined according to the valid version of EN60456

Information for test institutes: During a test in compliance with the applicable standard EN60456, you must select the maximal possible spin speed.

The programme **Cottons colour** complies with the requirements of the standard Cottons 60 °C standard programme and the standard Cottons 40 °C programme in accordance with the (EU) Regulation No. 1015/2010.

Information on residual moisture based on programme-dependent spinspeed limit and maximum loads.

Programme setting with maximum speed for testing and energy labelling in accordance with Directive 2010/30/EU with cold water (15 °C). These programmes are suitable for cleaning normally soiled cotton laundry and are the most efficient in terms of combined energy and water consumptions. The stated programme temperature is based on the temperature indicated on the care label for the laundry. The actual washing temperature may differ from the stated programme temperature for energy-saving reasons, the washing performance index meets the legal requirements.







Thank you for buying a **Bosch Home Appliance!**

Register your new device on MyBosch now and profit directly from:

- · Expert tips & tricks for your appliance
- · Warranty extension options
- Discounts for accessories & spare-parts
- Digital manual and all appliance data at hand
- Easy access to Bosch Home Appliances Service

Free and easy registration – also on mobile phones: www.bosch-home.com/welcome



Looking for help? You'll find it here.

Expert advice for your Bosch home appliances, help with problems or a repair from Bosch experts.

Find out everything about the many ways Bosch can support you: www.bosch-home.com/service

Contact data of all countries are listed in the attached service directory.