

Series 2, Free-standing dishwasher, 60 cm SMS50T02GB







Optional accessories

SGZ1010	inlet and outlet hose extention
SMZ2014	Rack insert for stemware dishwasher
SMZ5000	Dishwashing aid set
SMZ5001	Baby care kit
SM75002	Silver polishing cassette

The ActiveWater dishwasher with height-adjustable top basket: Gives you extra space for large and bulky items.

- Height Adjustable Top Basket: offers extra space, especially for tall dishes.
- Multiple water protection: for optimum security against flooding.
- Active Water: less water, less energy, better performance.
- EcoSilence Drive: especially energy-saving and silent in operation with a particularly high life span.
- 10-year guarantee: our convincing promise of quality against rusting of the inner tub.

Technical Data

Maximum number of place settings:		
The water consumption of the eco programme in liters per cycle:12.0		
l		
Built-in / Free-standing:	Freestanding	
Height of removable worktop:	30 mm	
Dimensions of the product (HxWxD):	.845 x 600 x 600 mm	
Depth with open door 90 degree:	1155 mm	
Adjustable feet:	Yes - all	
Maximum adjustability feet:	20 mm	
Adjustable plinth:	No	
Net weight:	45.2 kg	
Gross weight:	46.5 kg	
Fuse protection:	13 A	
Voltage:	220-240 V	
Frequency:	60; 50 Hz	
Length electrical supply cord:	175.0 cm	
Plug type:	GB plug	
Length inlet hose:	165 cm	
Length outlet hose:		
EAN code:	4242002707921	
Installation typology:Free-standing with b	uilt under possibility	



¹ Scale of Energy Efficiency Classes from A to G

Energy consumption in kWh per 100 cycles (in programme Eco 50 °C)

³ Duration of programme Eco 50 °C



Series 2, Free-standing dishwasher, 60 cm SMS50T02GB

The ActiveWater dishwasher with height-adjustable top basket: Gives you extra space for large and bulky items.

Performance

- Energy Efficiency Class: A+
- Capacity: 12 place settings
- Energy consumption in Eco 50 programme: 1.02 kWh
- Energy consumption in programme Eco 50 °C: 290 kWhper year, based on 280 standard cleaning cycles using cold water fill and the consumption of the low power modes. Actual energy consumption will depend on how the appliance is used.
- Power consumption off-mode / left-on mode: 0.1 W / 0.1 W
- Duration of the left-on mode: 0 minutes
- Water consumption in Eco 50 programme: 12 litres
- Water consumption in Eco50 programme: 3360 litres per year, based on 280 standard cleaning cycles
- Programme time in Eco 50 programme: 210 minutes
- A rated performance for washing and A for drying
- Noise level dB (A) re 1pW: 50 dB

Programmes/functions

- 5programmes:
- Intensive 70 °C, Normal 65 °C, Eco 50 °C,
- Quick wash 45 °C, Pre-Rinse
- 4 temperatures
- 1 Special option: Half Load

Flexible design elements

- Vario baskets
- Height adjustable top basket when empty
- Lower rack handle: no handle
- 2 foldable plate racks in bottom basket
- Upper rack cup shelf
- Knife rack in top basket

Innovations and technology

- EcoSilence BLDC drive
- Heat exchanger.
- ActiveWater hydraulic water system
- DosageAssist detergent dispenser
- Automatic detergent detection
- Load Sensor
- AquaMix Glass protection system
- Leak protection system

Design features

- Large item spray head
- Stainless steel/Polinox interior
- Control buttons on front of fascia
- Display colour: Red LED indicators
- LED salt refill indicator, LED rinse aid refill indicator
- Alternating spray arms

- Regenerative electronics
- Self cleaning filter system with 3 piece corrugated filter
- Servo lock for effortless door closing
- Time delay (3, 6 or 9 hours)
- Dimensions (HxWxD): 84.5 x 60 x 60cm
- Efficiency information relates to the Eco50 programme. This programme is suitable for cleaning normally soiled tableware and is the most efficient programme in terms of combined energy and water consumption.