

Series 6, Free-standing dishwasher, 60 cm, White SMS58M32GB









Optional accessories

SGZ1010 inlet and outlet hose extention
SMZ2014 Rack insert for stemware dishwasher

SMZ5001 Baby care kit SMZ5300 GlassSecure Tray

Our ActiveWater 60cm dishwasher with VarioFlex basket system and VarioDrawer: Gives you greater flexibility for better use of space.

- VarioDrawer: 3rd level loading for cutlery and smaller kitchen utensils.
- Rackmatic: even more adjustment options and thus maximum flexibility.
- LED Display: easy program selection with display of remaining time, rinse aid and salt refill status.
- Multiple water protection: for optimum security against flooding.
- EcoSilence Drive: especially energy-saving and silent in operation with a particularly high life span.

Technical Data

Maximum number of place settings:
Installation type:Freestanding
Height of removable worktop:
Dimensions of the product (HxWxD):845 x 600 x 600 mm
Depth with open door 90 degree:
Adjustable feet: Yes - all
Maximum adjustability feet:
Adjustable plinth:
Net weight:49.6 kg
Gross weight:51.0 kg
Fuse protection:13 A
Voltage:
Frequency: 50; 60 Hz
Length of electrical supply cord:175.0 cm
Plug type:GB plug
Length inlet hose:
Length outlet hose:
EAN code:
Installation type:Free-standing with built-in possibility





Series 6, Free-standing dishwasher, 60 cm, White SMS58M32GB

Our ActiveWater 60cm dishwasher with VarioFlex basket system and VarioDrawer: Gives you greater flexibility for better use of space.

Performance

- Capacity: 14 place settings. VarioDrawer on 3rd level
- Energy consumption in programme Eco 50 °C: 299 kWhper year, based on 280 standard cleaning cycles using cold water fill and the consumption of the low power modes. Actual energy consumption will depend on how the appliance is used.
- Water consumption in Eco50 programme: 2660 litres per year, based on 280 standard cleaning cycles
- Programme time in Eco 50 programme: 210 minutes
- Noise level dB (A) re 1pW: 48 dB

Programmes/functions

- 5programmes:
- Intensive 70 °C, Auto 45-65 °C, Eco 50 °C,
- Quick wash 45 °C, Pre-Rinse
- 2 Special options: VarioSpeed, Extra Dry

Flexible design elements

- VarioDrawer loading of cutlery on 3rd level
- 3 stage Rackmatic height-adjustable top basket
- Lower rack handle: Bosch plastic
- 2 foldable plate racks in top basket
- 4 foldable plate racks in bottom basket
- Upper rack cup shelf

Innovations and technology

- EcoSilence BLDC drive
- Heat exchanger.
- ActiveWater hydraulic water system
- DosageAssist detergent dispenser
- Automatic detergent detection
- AquaMix Glass protection system
- Leak protection system

Design features

- Stainless steel interior
- Control buttons on front of fascia
- Display colour: Red LED indicators
- LED salt refill indicator, LED rinse aid refill indicator
- Time delay (3, 6 or 24 hours)
- Alternating spray arms
- Self-cleaning filter system with 3 piece corrugated filter
- Dimensions (HxWxD): 84.5 x 60 x 60cm
- Efficiency information relates to the Eco50 programme. This programme is suitable for cleaning normally soiled tableware and is the most efficient programme in terms of combined energy and water consumption.