

**Series 6, Free-standing dishwasher,  
45 cm, Silver inox  
SPS53E18GB**



**The ActiveWater 45 with VarioFlex basket system: Gives you greater flexibility in the top and bottom racks.**

- **Vario Flex baskets:** easily adjustable to create more space for your dishes.
- **Rackmatic:** even more adjustment options and thus maximum flexibility.
- **LED Display:** indicates remaining program time and salt and rinse aid refill reminders.
- **AquaStop:** Bosch's warranty in case of water damage – throughout the lifetime of the appliance.\*
- **EcoSilence Drive:** especially energy-saving and silent in operation with a particularly high life span.

**Technical Data**

Maximum number of place settings: .....	9
The water consumption of the eco programme in liters per cycle: 9.0 l	
Built-in / Free-standing: .....	Freestanding
Height of removable worktop: .....	30 mm
Dimensions of the product (HxWxD): .....	845 x 450 x 600 mm
Depth with open door 90 degree: .....	1155 mm
Adjustable feet: .....	Yes - all
Maximum adjustability feet: .....	20 mm
Adjustable plinth: .....	No
Net weight: .....	41.2 kg
Gross weight: .....	42.5 kg
Connection rating: .....	2400 W
Fuse protection: .....	13 A
Voltage: .....	220-240 V
Frequency: .....	50; 60 Hz
Length electrical supply cord: .....	175.0 cm
Plug type: .....	GB plug
Length inlet hose: .....	165 cm
Length outlet hose: .....	205 cm
EAN code: .....	4242002670911
Installation typology: .....	Free-standing with built under possibility

**Optional accessories**

SGZ1010	inlet and outlet hose extention
SGZ3003	Silver polishing cassette
SMZ5000	Dishwashing aid set
SMZ5001	Baby care kit
SMZ5300	GlassSecure Tray



## **Series 6, Free-standing dishwasher, 45 cm, Silver inox SPS53E18GB**

### **The ActiveWater 45 with VarioFlex basket system: Gives you greater flexibility in the top and bottom racks.**

- Servo lock for effortless door closing
- Time delay (3, 6 or 24 hours)
- Dimensions (HxWxD): 84.5 x 45 x 60cm
- Efficiency information relates to the Eco50 programme. This programme is suitable for cleaning normally soiled tableware and is the most efficient programme in terms of combined energy and water consumption.

#### **Performance**

- Capacity: 9 place settings
- Energy consumption in Eco 50 programme: 0.78 kWh
- Energy consumption in programme Eco 50 °C: 220 kWhper year, based on 280 standard cleaning cycles using cold water fill and the consumption of the low power modes. Actual energy consumption will depend on how the appliance is used.
- Water consumption in Eco50 programme: 2520 litres per year, based on 280 standard cleaning cycles
- Programme time in Eco 50 programme: 170 minutes
- Noise level dB (A) re 1pW: 48 dB

#### **Programmes/functions**

- 5programmes:
- Intensive 70 °C, Auto 45-65 °C, Eco 50 °C,
- Quick wash 45 °C, Pre-Rinse
- 4 temperatures
- 2 Special options: Intensive Zone, VarioSpeed

#### **Flexible design elements**

- Vario Flex baskets
- 3 stage Rackmatic height-adjustable top basket
- Lower rack handle: Bosch plastic
- 2 foldable plate racks in top basket
- 2 foldable plate racks in bottom basket
- Upper rack cup shelf

#### **Innovations and technology**

- EcoSilence BLDC drive
- DuoPower spray arm in upper basket
- Heat exchanger.
- ActiveWater hydraulic water system
- DosageAssist detergent dispenser
- Automatic detergent detection
- AquaSensor III, Load Sensor
- AquaMix - Glass protection system
- AquaStop: Bosch's warranty in case of water damage - for the lifetime of the appliance. Please find warranty terms under <https://www.bosch-home.co.uk/customer-service/care-protection-and-parts/additional-warranties>

#### **Design features**

- Large item spray head
- Stainless steel interior
- Control buttons on front of fascia
- Display colour: Red LED indicators
- LED salt refill indicator, LED rinse aid refill indicator
- Alternating spray arms
- Regenerative electronics
- Self-cleaning filter system with 3 piece corrugated filter