

Series 4, free-standing dishwasher, 60 cm, White SMS50E92GC





SGZ1010 SMZ2014 SMZ5001 inlet and outlet hose extention Rack insert for stemware dishwasher Baby care kit The ActiveWater 60 with Rackmatic: Adjusts up and down 5 cm in three steps to give you more room for dishes, even when fully loaded.

- Silence Plus: pleasantly quiet at 48 dB.
- Rackmatic: top basket adjustable on three levels offers additional space, especially for tall dishes.
- 7-Segment Display: indicates remaining time and standard info, such as re-fill status.
- AquaStop: 100% lifetime warranty for water damages guaranteed.
- Child lock on door: prevents undesigned door opening during rinsing.

Maximum number of place settings:	10
The water consumption of the eco programme in	
2017/1369):	
Water consumption:	
Total annual energy consumption 220 days:	
Total annual water consumption 220 days:	
Built-in / Free-standing:	
Removable top:	
Door panel options:	
Height of removable worktop:	•
Height of the appliance:	
Adjustable feet:	
Maximum adjustability feet:	
Adjustable plinth:	
Net weight:	
Gross weight:	
Connection rating:	
Fuse protection:	
Voltage:	
Frequency:	
Length electrical supply cord:	
Plug type:	
Length inlet hose:	, ,
Length outlet hose:	
Hidden heating element:	
Water protection system description: Triple w	
Child saftety devices:	
Water softener:	
Top basket type: Practical loading wi	
Adjustable upper basket:	
Bottom basket type:	_
3.	
3rd Rack:	
Included accessories :	•
Number of place settings:	
Color / Material panel:	
Dimensions of the packed product (HxWxD):	880x660x680 mm





Series 4, free-standing dishwasher, 60 cm, White SMS50E92GC

The ActiveWater 60 with Rackmatic: Adjusts up and down 5 cm in three steps to give you more room for dishes, even when fully loaded.

- SMS50E92GC »SilencePlus, Serie 4«
- ActiveWater 60 cm dishwasher
- Freestanding White
- Capacity: 12 place settings
- Energy consumption in programme Eco 50 °C: 234 kWhper year, based on 280 standard cleaning cycles using cold water fill and the consumption of the low power modes. Actual energy consumption will depend on how the appliance is used.
- Energy consumption in programme Eco 50 °C: 0.835 kWh
- Water consumption in programme Eco 50 $^{\circ}\text{C}\colon 3108$ litres per year, based on 280 standard cleaning cycles. Actual water consumption will depend on how the appliance is used.
- Water consumption in programme Eco 50 °C: 11.1 l
- The information relates to the programme Eco50 °C. This programme is suitable to clean normally soiled tableware and is the most efficient programme in terms of combined energy and water consumption.
- Programme time in programme Eco 50 °C: 210 min
- Noise level: 48 dB(A) re 1 pW
- 5programmes:
- Intensive 70 °C, Auto 45-65 °C, Eco 50 °C, Quick wash 45 °C,
- 1 special option: Half Load
- 4 cleaning temperatures
- Heating pump
- DosageAssist
- AquaSensor
- Detergent Automation
- EcoSilence Drive
- Interior tub material: Stainless Steel/Polinox
- Alternating spray
- Self-cleaning filter system with 3-fold corrugated filter
- Remaining programme time indicator (min)
- Colour of indicators: red
- Electronic delay timer: 1-24 hours
- LED salt refill indicator
- LED rinse aid refill indicator
- Programme selector with integrated start button
- Vario basket system
- silver/dark grey
- Rackmatic height-adjustable top basket (3 stage)
- 2 foldable plate racks in bottom basket
- Cutlery rack in top basket
- Cutlery basket in bottom basket
- 2 cup shelves in top basket
- AquaStop: Bosch warranty in case of water damage for the

- lifetime of the appliance.*
- Childproof door lock
- Servo-lock
- Glass protection technology
- Product dimensions (HxWxD): 84.5 x 60 x 60 cm

General Specifications

Programmes

Features

Baskets & Racks

Safety

Technical Information



Series 4, free-standing dishwasher, 60 cm, White SMS50E92GC

