

Laundry Accessory WTZPA20UC



Works with Bosch Dryers WTG86403UC, WTW87NH1UC, WTG865H4UC

- Works with Bosch Dryers WTG86403UC, WTW87NH1UC, WTG865H4UC. Plugs Into Home's 4-Prong Receptacle and Has Two Power Outlets on the Front - One Each For Your Bosch Dryer and Washer to Plug Into
- Your New Bosch Dryer Comes with a Power Adapter Included in the Drum; This Accessory is Offered in the Case if it is Lost or Damaged and a Replacement is Needed
- Plugs Into Standard 4-Prong Receptacle (NEMA 14-30R) and From the Front, Two Receptacles Power Both the Bosch Washer and Dryer (2 x NEMA 6-15)

